

DAC-360

Installation manual

Version 2.6

PREFACE

In this installation manual you find information how to connect and program a DAC-360 shear control for operation with an industrial shear.

LIMITED WARRANTY

- The equipment is supplied by Delem without safety features. The machine manufacturer has to ensure a safe environment.
- This equipment must be installed and used in accordance with Delem's specifications. The guarantee on the equipment is invalidated in the event of improper installation and/or use of this equipment.
- The General Terms and Conditions of Delivery of Delem shall apply to this product. These conditions are available from Delem on request.
- This manual does not entitle you to any rights. Delem reserves the right to change this manual without prior warning.
- All rights reserved. The copyright is held by Delem. No part of this publication may be copied or reproduced without written permission from Delem BV.

Table of contents

Parameter index	5
Part I - Hardware description	
1. Introduction	1.2
2. Specifications	1.3
2.1. Physical dimensions	1.3
2.2. Environmental conditions	1.3
2.3. Technical specifications	1.4
3. System I/O	1.5
3.1. Introduction	1.5
3.2. Power supply / Analog output	1.6
3.3. Analog I/O	1.6
3.4. Digital I/O	1.7
3.5. Encoder	1.8
4. Spare parts	1.9
5. Schematics	1.10
Part II - Machine settings	
1. Machine parameter types	2.2
1.1. Menu	2.2
1.2. Control types	2.2
1.2.1. Servo drive	2.2
1.2.2. AC drive	2.3
1.2.3. Unipolar system	2.5
1.3. Spindle correction table	2.6
2. The machine parameters	2.8
2.1. General parameters	2.8
2.2. Backgauge control parameters	2.10
2.2.1. General	2.10
2.2.2. Encoder	2.14
2.2.3. Retract	2.17
2.2.4. Return-to-Sender	2.19
2.2.5. Control	2.20
2.2.6. I/O	2.29
2.3. Angle control parameters	2.30
2.4. Gap control parameters	2.33
2.4.1. GAP	2.33
2.4.2. GAP 2	2.36
2.5. Stroke control parameters	2.37
2.6. Force control parameters	2.41
2.6.1. Main force	2.41
2.6.2. Clamping force	2.48
2.7. Part support	2.50
3. I/O assignments	2.53

3.1. Introduction	2.53
3.2. List of I/O signals	2.55
4. Software settings	2.58
4.1. Parameter back-up	2.58
4.2. Upgrade control	2.60
4.3. Special access codes	2.61
4.4. Display codes	2.62

Part III - Diagnostic program

1. Introduction	3.2
1.1. Remarks	3.2
1.2. Test-menu	3.2
1.3. Test functions	3.3
1.4. Service screens	3.3

Parameter index

This index contains a list of all machine parameters described in this manual, in alphabetic order.

AC brake enable	2.25	I-gain	2.24
Acceleration ramp	2.29	In Position tolerance	2.30
Acceleration, 0 to max.	2.22	In position tolerance	2.32
Angle force enable	2.45	In position tolerance	2.34
Angle force ramp	2.47	In position tolerance	2.37
Angle material table	2.33	Limit speed	2.22
Angle prestop negative	2.31	Main force enable	2.41
Angle prestop positive	2.31	Main force reference table	2.41
Angle reference table	2.32	Manual speed high	2.11
Angle tolerance	2.31	Max RTS thickness	2.20
Angle/Gap force ramp	2.48	Maximum cutting length	2.8
Auto mode enabled	2.9	Maximum operating speed	2.21
Auto retract enable	2.17	Maximum stroke	2.38
Back zone	2.13	Maximum thickness	2.8
Brake delay	2.26	Maximum value	2.11
Brake point high speed <	2.26	Minimum retract	2.17
Brake point high speed >	2.27	Minimum stroke	2.38
Brake point low speed <	2.26	Minimum value	2.11
Brake point low speed >	2.26	Minimum retract	2.17
Braking ramp	2.29	Minimum stroke	2.38
Clamp force enable	2.44	Minimum value	2.11
Clamping force ramp	2.45	Number of FD functions	2.9
Clamping force ramp	2.48	Opening enable	2.40
Clamping reference table	2.49	Opening force ramp	2.43
Control enable	2.30	Overrun	2.21
Control enable	2.33	Overrun wait time	2.21
Control enable	2.36	P1: Angle/Gap force	2.47
Control enable	2.50	P1a: Angle Force	2.47
Control type	2.10	P1g: GAP Force	2.45
Count direction	2.14	P2: Clamping force	2.44
Cutting force factor	2.41	P2: Clamping force enable	2.48
Cutting force ramp	2.42	P4: Opening force	2.43
DC high speed <	2.28	Park PS_DN	2.52
DC high speed >	2.28	Park PS_UP	2.52
DC low speed <	2.27	P-gain	2.23
DC low speed >	2.28	Position angle after GAP	2.46
Deceleration, max. to 0	2.23	Positioning tolerance	2.25
Decimal point position	2.11	Pre scaling	2.14
Default FD functions	2.10	Prestop	2.40
Default part support	2.50	Prestop negative	2.34
Default retract	2.18	Prestop negative	2.37
Enable CY	2.9	Prestop positive	2.34
Enable display correction	2.12	Prestop positive	2.36
Fixed angle	2.30	Reference position	2.15
Front zone	2.13	Reference search	2.15
GAP force enable	2.45	Reference search direction	2.15
GAP force ramp	2.46	Reference search speed	2.16
Gap material table	2.35	Retract programmable	2.17
Gap reference table	2.35	Rotation offset	2.40
Gap2 reference table	2.37	RSD switch mounted	2.16
Idle force	2.50	RTS enable	2.20
		RTS forward speed	2.20
		Safety Zone	2.19
		Sheet position mode	2.38
		Spindle allowance	2.20
		Spindle correction table	2.14
		Stop deceleration	2.23
		Stop time	2.27
		Stroke mode	2.37
		Stroke reference table	2.39
		T1: Cutting force delay	2.42

T10: Angle/Gap force dly	2.48
T11: Angle force delay	2.47
T12: Angle after GAP delay	2.46
T13: PS_DN delay	2.51
T14: PS_DN pulse	2.51
T15: PS_UP delay	2.51
T16: PS_UP pulse	2.51
T2: Clamping force delay	2.49
T3: Opening force delay	2.43
T4: Blade-up hold time	2.43
T5: Clamping time	2.44
T5: Clamping time	2.49
T6: Clamping force delay	2.44
T6: GAP force delay	2.46
T7: Stroke time	2.39
T8: Retract hold time	2.18
T9: Retract delay	2.18
Tracking error enable	2.24
Tracking error margin	2.24
Unipolar	2.29
X/Gap correction enable	2.12
X-correction enable	2.13
X-limit	2.22
X-speed programmable	2.10

Part I - Hardware description

This section contains the hardware specifications of a Delem DAC-360 control.



1. Introduction

The DAC-360 is a universal programmable control, designed to control positioning of machine parts such as the backgauge control of an industrial shear. The control is capable of controlling servo-loop systems, a one- or two-speed AC or DC drive system.

2. Specifications

2.1. Physical dimensions

For the dimensions of the control, see the included drawings at the end of this section.

2.2. Environmental conditions

The following environment specification values are valid for a DAC-360 control:


Ambient temperature	5 - 50°C
Storage temperature	min. -20°C max. 70°C
Relative humidity	max. 90 % non-condensing
EMC	designed and built to meet the following standards: EN50081-2 EN50082-2
Protection rate	IP54 when built-in, assuming the enclosure is also IP54

2.3. Technical specifications

Power supply	18 - 28 VDC 5W (I/O excluded)
Display	LCD/STN resolution 320 x 240 black/white
Interfaces	1 x Encoder, max. 1 MHz 1 x RS-232
I/O	8 x Digital input, 24V 16 x Digital output, 24V 1 x analog output 0 +/- 10V 2 x analog output 0 - 10V 3 x analog input 0 - 10V (each incl. 10V ref.)

3. System I/O

3.1. Introduction



The backside of the control is equipped with a set of connectors for various functions:


- system I/O
- encoder feedback
- communication

The various connectors are discussed in the following sections.

Warning:

Connectors may not be plugged or unplugged when power is ON. Connectors may only be connected or disconnected when power is OFF.


3.2. Power supply / Analog output



Connector CN4 contains the connection for the power supply and the analog output for axis movement.

Power supply	18 - 28 VDC 5W (I/O excluded)
Analog output	0 +/- 10V 10mA max.

3.3. Analog I/O




The Analog connector CN19 provides several analog signals, two analog outputs and three analog inputs.

See schematic 8062-101 for connection details.
Specifications for Analog I/O:

analog inputs (3x)	0-10V, input impedance 44 k Ω
reference voltage (3x)	10V \pm 2%, minimal resistance 1 k Ω
analog outputs (2x)	0 - 10V 10mA max. minimal resistance 1 k Ω

3.5. Encoder



9-pole SUBD female encoder interface

power supply:
5V DC/250 mA or 12V DC/200 mA

possibilities:
12 V single ended
5 V single ended
5 V differential
Max. count frequency 1 MHz

See schematic 8062-101 for connection details.

Notes:

- In case of 12VSE encoder, connect pins 6, 7, 8 and 9 with each other.

4. Spare parts

The following table gives an overview of the available spare parts for the DAC-360 control.

Number	Description
FRONT-360	Front panel DAC-360
DLCD-360	LCD screen
D-7453-001	Mainboard DAC-360

5. Schematics

The following pages show several schematics about the DAC-360 control:

8062-901	Mounting dimensions
8062-912	Cables and connectors
8062-101	Connection diagram
8062-103	Connection diagram
8062-104	Connection diagram
8062-107	Connection diagram
8062-108	Connection diagram
	Timing diagrams



I/O, INPUTS & OUTPUTS

DC-161586
Clamping-yoke connection (screw)



DC-177988
Spring connection


DC-178909
Spring connection + Led indication




1 x Power LED
8 x I/O LED

POWER & ANALOG OUTPUTS


DC-161582
Clamping-yoke connection (screw)



ENCODER 1








ANALOG



Note	Redrawn	Date	
Description			
Note	Redrawn	Date	
Description			
Measures in mm, unless otherwise specified	Drawn	HNF	Date
			21-03-2007

Delem Luchthavenweg 42, 5657 EB Eindhoven, the NETHERLANDS			
DAC-360 cables & connectors			
Format	Number	Issue	
A3	8062-912	-	
No unauthorized copying allowed			



Note 1 : Leave unconnected pins open.

Note 2 : 24V relays supply must be separated from 24V supply






See drawing 8062-901 for mounting dimensions.





Note C	Redrawn	HNF	19.05.2011
Description	EOS I/O allocation added.		
Note C1	Redrawn	HNF	29.06.2010
Description	Maintenance#4767 I/O allocation optimized, 8062-907 removed		
Measure in mm unless otherwise specified	Drawn	HNF	24.01.2007

Delem
Inchthavenweg 42, 5657 BB
Eindhoven, the NETHERLANDS


Example connections:
AC X-Axis Single- / Dual-speed + brake, Gap
Angle control, Stroke(IN3)

Page 1 / 1
Frame A3
8062-104
C1





* See connection diagram: 9087-101 for details "Inverter modes"








Note 1 : Leave unconnected pins open.
 Note 2 : 24V relays supply must be separated from 24V supply

See drawing 8062-901 for mounting dimensions.


Note C	Redrawn	HNF	19-05-2011
Description	Maintenance#2322		
Note C1	Redrawn	HNF	29-06-2010
Description	Maintenance#2767		
I/O allocation optimized 8062-907 removed			
Measure in mm unless otherwise specified	Drawn	HNF	24-01-2007

Example connections:
 AC X-Axis Unipolar inverter
 Gap 2 control/Angle control
 Angle/Stroke(IN2)
 Encoder 1




*See connection diagram: 9087-102 for details "OK & START"


Digital Input allocation







Digital Output allocation



Analog Input allocation



Analog Output allocation



Note 1 : Leave unconnected pins open.

Note 2 : 24V relays supply must be separated from 24V supply

INPUTS / OUTPUTS 10 POLE MALE

CN1	CN2	CN3
OUT-1	OUT-9	OUT-17
OUT-2	OUT-10	OUT-18
OUT-3	OUT-11	OUT-19
OUT-4	OUT-12	OUT-20
IN-5	IN-13	OUT-21
IN-6	IN-14	OUT-22
IN-7	IN-15	OUT-23
IN-8	IN-16	OUT-24
0V	0V	0V

INPUTS / OUTPUTS 6 POLE MALE

CN4
POWER IN +24...28VDC
POWER IN 0V
A1-OUT -10V...+10V
A1-0V
Not connected
Not connected

SERIAL 9 POLE MALE

CN5
1 Not connected
2 Requested Data
3 Transmitted Data
4 Not connected
5 Signal Ground
6 Requested Send
7 Clear to Send
8 Not connected
9 Not connected

ENCODER 9 POLE FEMALE

CN7	12VSE	5VSE	5VDE
1 TO (REF)	T0	T0	T0
2 T2 (B)	T2	T2	T2
3 T1 (A)	+12V	T1	T1
4 +10V	GND	GND	GND
5 GND	GND	GND	+5V
6 TO (REF)	/	/	/
7 T2 (B)	/	/	/
8 T1 (A)	+5V	/	/
9 +5V	/	/	/

In case of 12VSE bridge pins 6,7,8 and 9

ANALOG 15 POLE MALE

CN9
1 OUTANA1 0V...+10V
2 OUTANA1 0V
3 REF1 10V
4 INA1
5 INA1 0V
6 INA2
7 INA2 0V
8 REF2 10V
9 OUTANA2 0V...+10V
10 OUTANA2 0V
11 REF3 10V
12 INA3
13 INA3 0V
14 N.C.
15 N.C.


See drawing 8062-901 for mounting dimensions.

Delem
 Inchtshavenweg 42, 5657 BB
 Eindhoven, the NETHERLANDS

Example connections:
 AC X-Axis Single- / Dual-speed + brake, Gap
 Gap 2 control/Angle control ,Angle/Stroke(IN2)

Note C	Redrawn	HNF	Date	19.05.2011
Description	EOS I/O allocation #232			
Note C1	Redrawn	HNF	Date	29.06.2010
Description	Maintenance#2767			
I/O allocation optimized, 8062-907 removed				
Measure in mm unless otherwise specified	Drawn	HNF	Date	24.01.2007
Page 1 / 1	8062-108	C1	No unauthorized copying allowed	

DAC-360 with stroke potentiometer




- S0 = Controller Stopped
- S1 = Positioning
- S2 = Wait for ST low
- S3 = Wait for EOS
- S4 = Wait for UDP
- S5 = Wait for ST high

- T1 = Cutting force delay
- T5 = Clamping time
- T6 = (main) Clamping force delay

* = UDP high only if UDPIN high in case of:
gauge position inside safety zone or
Angle needs adjustment
in case of combined potentiometer

DAC-360 pressure outputs




- S0 = Controller Stopped
- S1 = Positioning
- S2 = Wait for ST low
- S3 = Wait for EOS
- S4 = Wait for UDP
- S5 = Wait for ST high

- T1 = Cutting force delay
- T2 = Clamping force delay
- T3 = Opening force delay
- T4 = Blade up hold time
- T5 = Clamping time
- T6 = (main) Clamping force delay


- p1 = Angle/Gap force
- p2 = Main clamping force
- p3 = Cutting force
- p4 = Opening force
- p5 = Clamping force

NOTE: in case Clamping force is disabled, T2 will be 1/2 T6.


DAC-360 Interrupted cycle with Blade Return (BR)




DAC-360 Interrupted cycle with PEDAL




DAC-360 with timed stroke




DAC-360 Retract Timing




DAC-360 Retract Timing (Wait for Retract)




DAC-360 Angle after gap



DAC-360 Part support



DAC-360 Start/Stop Timing



- 1) On the rising as well as the falling edge of Machine Ready (MR), the axes setpoints are set to their actual position.
- 2) The step change event is either the rising edge of Step (ST) or the rising edge of Start (NCS). Upon the stepchange event, all axes start to move (unless some other condition prevents them from moving).

Part II - Machine settings


This section will describe the necessary settings of a DAC-360 control regarding machine settings. <https://www.machinemfg.com/>

1. Machine parameter types

1.1. Menu

The machine parameters are only accessible with a special entry code. Machine parameters should be adjusted by authorized personnel only. To enter the machine parameters menu:

- go to the screen with program constants;
- place the cursor on parameter 124 "service menu";
- enter the code 852;
- press ENTER.



2.a

From this menu, the several types of machine parameters can be edited. To enter a menu with parameters, move the cursor bar to the correct menu and press ENTER. Press the Stop button to exit a menu or to return to normal operation mode.

In the next chapter the machine parameters are explained. The following sections in this chapter describe the different control systems that are supported.

1.2. Control types

The control can be programmed to control different axis types:


- 1-speed AC or DC drive
- 2-speed AC or DC drive
- Servo motor drive

The required system can be programmed with the parameter 'Control type'.

1.2.1. Servo drive

The following servo parameters are available:

- Maximum operating speed
- Acceleration
- Deceleration
- Emergency deceleration
- P-gain
- I-gain



2.b

The following adjustment procedure can be followed to set the parameters to correct values. Changes in the settings should be checked by moving the axis from one position to another. This stroke should be large enough, so that the axis will reach its maximum speed.

- Set the standard machine parameters, like minimum value, maximum value, scale factor etc., to the correct values.
- Set the maximum operating speed to the correct value. This is the speed of the axis, in mm/s, when the output of the module to the motor amplifier is 10V. If required the speed can be set to a lower value.
- Set the acceleration and deceleration ramp parameters to safe values, for example 500ms or more. Of course these values depend on the actual combination of motor, motordrive and load.
- Set the gain parameters to safe default values, for example:
 - P-gain = 2.50
 - I-gain = 1
- Increase the P-gain until you notice oscillation during the movement and especially at the end position. Reduce the P-gain again to the point where there was no oscillation.
- Increase the I-gain until you notice oscillation at the end position. Reduce the I-gain again to the point where there was no oscillation.
- Optimise the acceleration and deceleration times. Reduce these times until you find an optimal compromise between a fast and smooth movement. If one of these values is set too small, it will lead to irregular behaviour of the axis during acceleration or deceleration.

1.2.2. AC drive

In this paragraph, the parameters for axes with AC drives are discussed. When using AC drives, it is possible to program 1-side positioning or 2-side positioning. Beside this, it must be indicated whether a one-speed or 2-speed motor drive is used. With these parameters you can optimize the positioning accuracy of the AC-axis:

- Brake point high speed (BHS)
- Brake point low speed (BLS)
- Overrun (OR)
- Overrun wait time
- Stop time (T)
- DC low speed
- DC high speed
- AC-brake enable

For the movement control of the axis there are two possibilities:


- two, three or four digital outputs of the module;

- one analog output signal.

The type of control can be specified as on-off control. When there is a position error, the control signal is on. When there is no position error, the control signal is off.

- 1-speed AC axis

For a 1-speed axis, the parameter 'axis type' must be set to 1. This axis can be driven through 2 digital outputs or through the analog output.




2.c

For this axis, the parameter 'Brake point low speed' (BLS) must be programmed. This parameter defines the switch-off points for the axis movement. The value depends on the known deceleration rate of the axis equipment. If the BLS is not accurate enough to reach the programmed position, the parameter 'Stop time' (T) can be used for further fine-tuning of the positioning.

If the axis is controlled through the analog output, the parameter 'DC slow speed' must be programmed to a correct value.

- 2-speed AC axis

For a 2-speed axis, the parameter 'axis type' must be set to 2. This axis can be driven through 3 or 4 digital outputs or through the analog output. The axis can be controlled at two different speed levels.



2.d

For this axis, the parameters 'Brake point low speed' (BLS) and 'Brake point high speed' (BHS) must be programmed. These parameters define the switch-off points for high and low


speed for the axis movement. As with the 1-speed axis, the parameter 'Stop time' (T) can be used to improve positioning.

If the analog output is used for axis control, the parameters 'DC high speed' and 'DC low speed' must be programmed at two different values. These values determine the voltage levels at the analog output for the two different speed settings.

- One side positioning:

In the explanations above, the control systems used two-side positioning. So when moving from high to low or vice versa, positioning takes place instantly.

In some cases, it is desired to have positioning only in one direction.



2.e

One side positioning is useful to overcome mechanical inaccuracies in the spindle. Final positioning of the axis is always done from a higher to a lower position. So when the axis moves from a high to a low position, positioning is done immediately. When the axis moves from a low to a high position, the axis will move to the overrun position (= programmed position +OR). After that, the axis starts moving in the opposite direction and positioning takes place.

When the difference between the new programmed position and the actual position is smaller than BLS the axis is always moved to the overrun position first, also in case of two side positioning.

Choosing 1-side or 2-side positioning is done with the parameter 'Spindle allowance'.

- AC brake


The control can be programmed to support a brake on the AC motor. This can be activated with the parameter 'AC-brake enable'. The motor brake is activated as soon as the speed control is zero.

The brake signal is designed according to fail-safe principle: the signal is TRUE if the axis must move, the signal is FALSE if no movement is allowed (the brake is active).

1.2.3. Unipolar system

Normally, the analog output can be used for movement control: positive voltage for one direction, negative voltage for the other direction.

In a unipolar system the output voltage is always positive, the movement direction is indicated by digital outputs.




A unipolar system can be implemented for servo and AC drives.

1.3. Spindle correction table

The spindle correction table is meant to overcome axis position errors due to mechanical inaccuracies in the spindle.

If a spindle shows deviations then they should be measured systematically on certain setpoints. From these setpoints, a table with corrections can be created.



Corrections are calculated as follows:

$$\text{Cor} = X_m - P$$

X_m = programmed position

P = measured position

Cor = the necessary correction


Xm	P	Cor
X1	P1	Cor1
X2	P2	Cor2
...
Xn	Pn	Cor n

All measured axis positions and their corresponding corrections can be entered in a table on the control.

To access the correction table, proceed as follows:

- enter the machine parameters menu as described in chapter 1,
- enter the parameters for the backgauge,
- scroll to parameter 29, 'Spindle correction table',
- press ENTER.

The following screen appears:



Spindle correction table

	Position	Correction
1	1.0	0.02
2	50.0	-0.04
3	100.0	0.02
4	150.0	-0.03
5	200.0	0.04
6	300.0	0.01

Each line consists of the line number, the axis position (Pos) and the necessary correction (Cor).

The table can be edited as follows:

- Use the arrow keys to move up, down, left and right.
- To add a row, go to the first column and press the ENTER key.
- To delete a row, go to the first column of the previous row and press the Clear key. All rows after the current row will be deleted!
- To enter a value, move to the required cell, type the value and press ENTER.

A maximum of 20 corrections can be programmed in the table.

For positions between the programmed positions, a correction computed through linear interpolation.

2. The machine parameters

2.1. General parameters

Parameter 13 Maximum thickness

Range : 0.1 - 99.9
Unit : mm
Default : 1.0

Function


Pressing the ENTER key on this parameter opens a table. In this table program the maximum sheet thickness (per material ID) that the machine can cut.

Parameter 14 Maximum cutting length

Range : 0.0 - 15000.0
Unit : mm
Default : 1000.0

Function

The maximum length the machine can cut. This setting will effect the maximum possible sheet length, in combination with other settings.



2.f

Parameter 15 Auto mode enabled

Range : 0 - 1
Unit : -
Default : 1

Function

When this parameter is set to 1 (default value), all operation modes are available for the operator.

When set to 0, the operation modes "Programming" and "Program selection" are not available for the operator. The other modes will remain available. The tabs of these remaining modes are aligned to the left in the Navigation bar.



Parameter 16 Enable CY

Range : 0 - 1
Unit : -
Default : 1

Function

CY indicates the step repetition parameter. When CY is enabled, this parameter is activated and can be programmed in Programming / auto mode.

0 = CY not enabled, program step repetition is not possible

1 = CY enabled, program step repetitions can be programmed.

Parameter 17 Number of FD functions

Range : 0 - 4
Unit : -
Default : 0

Function

Program the number of available function outputs. These outputs are available for general purposes. The values of these function outputs can be programmed by the operator.

If this parameter is programmed larger than 0, the parameter 'Default value FD functions' appears.

Parameter 18
Default FD functions

Range : 0000 - 1111
Unit : -
Default : 0000

Function

Program a default value for the function outputs. This value must be programmed as a binary number, in which each digit represents a digital function output.

This parameter only appears when the parameter 'Number of FD functions' is programmed larger than 0.

2.2. Backgauge control parameters

2.2.1. General

Parameter 19
Control type

Range : 0 - 3
Unit : -
Default : 3

Function

The type of motor system that is to be controlled.

0 = No control

1 = 1-speed AC or DC drive

2 = 2-speed AC or DC drive

3 = Servo motor drive

According to this setting, parameters for Servo or for AC will appear for programming. See also chapter 1 about drive types.

Parameter 20
X-speed programmable

Range : 0 - 1
Unit : -
Default : 0

Remark

Only if 'Control Type' (19) is set to 3.

Function

This parameter defines whether or not the speed of the axis can be programmed in user mode. If enabled, then in programming mode and manual mode the operator can program the axis speed in a percentage of the maximum speed.

0 = no speed parameter for operator (default setting)

1 = speed programmable

Parameter 21 Minimum value

Range : 0.00 - 9999.99
Unit : mm
Default : 1.00

Function

Minimum backgauge position. The axis will never be controlled to a lower position than programmed here.

Parameter 22 Maximum value

Range : 0.00 - 9999.99
Unit : mm
Default : 1000.00

Function

Maximum backgauge position. The axis will never be controlled to a higher position than programmed here.

Parameter 23 Manual speed high

Range : 1 - 100
Unit : %
Default : 50

Function

Speed of the axis, when it is moved in manual mode with the 'manual move' function. This is the travel speed when the arrow key is pressed continuously. This parameter should be programmed as a percentage of the maximum speed.

Parameter 24 Decimal point position

Range : 0 - 2
Unit : -
Default : 1

Function

0 = 1 mm / 0.1 inch resolution
1 = 0.1 mm / 0.01 inch resolution
2 = 0.01 mm / 0.001 inch resolution

Parameter 25
X/Gap correction enable


Range : 0 - 1
Unit : -
Default : 0

Function

When this parameter is set to 1, the position value of the X-axis is adjusted according to adjustment of the Gap.

0 = no correction

1 = correction with Gap distance



Parameter 26
Enable display correction

Range : 0 - 1
Unit : -
Default : 0

Function

When the axis reaches the programmed position, the display can show the real measured position or it can show the programmed position. This can be programmed with this parameter.

If this parameter is programmed to 1, the display shows the programmed position when the axis position is within the 'In Position' tolerance.

0 = real actual values are shown

1 = programmed value is shown when axis in position

In both cases, the value is highlighted when the axis is within the IP tolerance.

Parameter 27 X-correction enable

Range : 0 - 1
Unit : -
Default : 0

Function

To provide an X-axis correction parameter for the operator. When switched on, the operator can program a global X-axis correction that is valid for each program step.

0 = no correction parameter available

1 = X-axis correction available

Parameter 123 Front zone

Range : 0 - 9999.99
Unit : mm
Default : 0.00

Function

This function can be used for example to switch support arms or a device to collect the products when cutting small pieces. The XFR output signal will be active when the **programmed** backgauge position is smaller than the limit programmed in this parameter. The output signal, XFR, can be mapped on an output pin in the I/O mapping menu.

X-programmed > Front zone => XFR = off

X-programmed < Front zone => XFR = on

Parameter 126 Back zone

Range : 0 - 9999.99
Unit : mm
Default : 0.00

Function

This function will be active when the **actual** backgauge position is larger than the limit programmed in this parameter. The output signal, XBACK, can be mapped on an output pin in the I/O mapping menu.

X-actual > Back zone => XBACK = on

X-actual < Back zone => XBACK = off

2.2.2. Encoder

Parameter 28 Pre scaling

Range : 1.000 - 9999.999
Unit : counts/mm
Default : 50.000

Function

Sets the scaling between encoder pulses and millimeters. The encoder gives an exact number of count pulses over a mm displacement. This value must be programmed here.

The value can be calculated by the formula:

$$F = (NP / SPP) * 4$$

in which:

- NP = Number of encoder pulses per revolution of the spindle
- SPP = Spindle pitch in mm

The result of the division NP/SPP is multiplied by 4, because the control counts every quadrant of one encoder cycle.

Example:

- number of encoder pulses: 50 pulse/rev.
 - spindle pitch: 2 mm/rev.
- results in $F = (50 / 2) * 4 = 100$ counts/mm

Parameter 29 Spindle correction table

Range : -
Unit : -
Default : -

Function

Entry point to edit a spindle correction table. Press ENTER to open a new window, in which the table can be edited. See chapter 3 for more information about the spindle correction table.

Parameter 30 Count direction

Range : 0 - 1
Unit : -
Default : 0

Function

To change the counting direction of the axis encoder pulses, in case the installed counting is incorrect.

Parameter 31 Reference search

Range : 0 - 1
Unit : -
Default : 1

Function

To choose whether or not to have a reference search cycle at start-up of the control.

0 = no reference search at power-on

1 = reference search

If programmed to 0, the control memorises the position when switched off. During operation, the actual position of the axis can be programmed with a parameter in the Program Constants, 'Actual X position'. <https://www.machinemfg.com/>

If programmed to 1, the control will initiate a reference search cycle at start-up. In this case, several other machine parameters will appear which need to be programmed.

Parameter 32 Reference search direction

Range : 0 - 1
Unit : -
Default : 1

Remark

Only if 'Reference Search' (31) is set to 1.

Function

Controls the direction of the reference search.

0 = Downcounting direction.

1 = Upcounting direction.

Parameter 33 Reference position

Range : 0.00 - 9999.99
Unit : mm
Default : 900.00

Remark

Only if 'Reference Search' (31) is set to 1.

Function

The position of the reference switch. This position is assumed when the reference has passed. The encoder must generate a pulse from low to high on the reference input.

Parameter 34 Reference search speed

Range : 1 - 100
Unit : %
Default : 50

Remark

Only if 'Reference Search' (31) is set to 1.

Function

Axis speed during reference searching.

Parameter 35 RSD switch mounted

Range : 0 - 1
Unit : -
Default : 1

Remark

Only if 'Reference Search' (31) is set to 1.

Function

0: reference search system without Reference Search Direction switch (RSD-switch).

1: reference search system with RSD-switch

0

This reference procedure monitors the movement of the axis. When reference searching is started, the axis is moved at the programmed speed in the programmed direction until it is stopped by an end-of-travel (EOT) switch. Shortly after stopping, the control detects no movement on the system and controls the axis in the reverse direction. Now the control will accept the first reference pulse from the encoder and assume the reference position at that point.

1

Here an RSD switch must be connected to the RSD input of the control. When reference searching is started, the axis is moved at the programmed speed (34) in the programmed direction (32) until the control receives a signal from the RSD switch (RSD input becomes low). The control will stop movement and send the axis in the reverse direction. Now as soon as the the RSD input becomes high again, the control will accept the first reference pulse from the encoder and assume the reference position (33) at that point.

In case the RSD switch is mounted in the middle of the X-axes stroke, the control can sense the status of this switch. In case the X-axis has not passed the RSD switch, a normal reference search cycle is initiated. In case the X-axis has passed the RSD switch, the status of the RSD switch indicates that reference search can start in the direction of the RSD switch (forward). Generally you will have shorter reference search cycle time. Another advantage is the fact that it is not needed to mount the limit switches for ref.-search.

Note:

The RSD input is designed for a switch with a normally-closed contact. Low is active, high is not active.

2.2.3. Retract

Parameter 36 Retract programmable

Range : 0 - 1
Unit : -
Default : 0

Function

When set to 1, the retract function is enabled. Several parameters (37-40) will become available and can be programmed.

Parameter 37 Auto retract enable

Range : 0 - 1
Unit : -
Default : 0

Remark

Only if 'Retract programmable' (36) is set to 1.

Function

When set to 1, retract is automatically started on the high-to-low transition of the input ST, which is the moment to start cutting.

When set to 0, the backgauge is only retracted when the R input becomes high.

Parameter 38 Minimum retract

Range : 0.0 – 9999.9
Unit : mm
Default : 0.0

Remark

Only if 'Retract programmable' (36) is set to 1.

Function

Minimum retract value.

Parameter 125
T9: Retract delay

Range : 0.0 - 9999
Unit : ms
Default : 0

Remark

Only if 'Retract programmable' (36) is set to 1.

Function

The retract of the X-axis will start when the R-input is activated. When auto retract is enabled, the retract will start on a high to low transition of the ST-input signal.

When a retract delay time is programmed, the retract will start when the R-input becomes high, or ST goes low in case of auto retract, and the programmed time delay time T9 has elapsed.

Parameter 39
T8: Retract hold time

Range : 0.0 - 999.9
Unit : seconds
Default : 0

Remark

Only if 'Retract programmable' (36) is set to 1.

Function

Holdtime, to keep the X-axis at the retract position.

Parameter 40
Default retract

Range : 0.0 – 9999.9
Unit : mm
Default : 0.0

Remark

Only if 'Retract programmable' (36) is set to 1.

Function

Default value for the retract distance when a new program is created.

Parameter 41 Safety Zone

Range : 0.0 – 9999.9
Unit : mm
Default : 0.0

Function

Safety zone for the X-axis.

If programmed to 0, this feature is not used.

If programmed higher than 0, this parameter defines a safety zone for the X-axis. During a cut, the X-axis should stay outside the zone to avoid collision.


The output XSAFE is used to indicate the X-axis status:

- TRUE if the X-axis is outside the zone ($X > \text{Safety zone}$);
- FALSE if the X-axis is inside the zone ($X < \text{Safety Zone}$).

2.2.4. Return-to-Sender

With the Return To Sender function the sheet can be pushed back to the front of the machine with the backgauge after a cycle. If enabled, the machine operator can activate the RTS function in every step of a program separately, as well as in manual mode.

At the end of a step with $\text{RTS}=1$ the controller will go to stop on a low to high transition of the ST input. Typically this will be when the blade reaches UDP. Now the operator can start the RTS movement by activating the RTSIN input. The backgauge will keep moving to the front as long as the input RTSIN is active. An output, RTS, will be activated when a step with $\text{RTS}=1$ is active. See also the following timing diagram:



When the start button is pressed again the backgauge will go to the programmed position.

Parameter 117
RTS enable

Range : 0 - 2
Unit : -
Default : 0

Function

Enable / disable the Return-to-Sender function.

0 = RTS disabled

1 = RTS enabled and RTS speed used for all program steps if in one or more program steps the RTS function has been enabled

2 = RTS enabled and RTS speed used only for the actual RTS function. For normal backgauge movements the normal programmed speed is used

Parameter 118
RTS forward speed

Range : 1 - 100
Unit : %
Default : 100

Function

The speed of the backgauge when moving to the front

Parameter 119
Max RTS thickness

Range : 0.1 - 99.9
Unit : mm
Default : 99.9

Function

The maximum sheet thickness (mm) with which the RTS function can be used. If the operator programs a higher thickness, the RTS parameter will not be available and at the same time an output signal, RTSTH, will be activated. The signal RTSTH can be mapped on an output pin in the I/O mapping menu.

2.2.5. Control

Parameter 42
Spindle allowance

Range : 0 - 1
Unit : -
Default : 1

Function

0 = one-side positioning

1 = two-side positioning (default)

In case of two-side positioning, the axis always moves directly to the programmed position. The one-side positioning can be selected to overcome mechanical tolerances with two side positioning. In case of one-side positioning the positioning direction is from a larger to a smaller position. See also chapter 1 about drive types.

Parameter 43 Overrun

Range : 0 - 9999

Unit : mm

Default : 1

Function

Overrun distance in case of one side positioning. One-side positioning is chosen with the parameter 'spindle allowance'(42). During a retract movement the overrun will not be performed.

An overrun is also done when an AC-drive must change position over a small distance, smaller than BLS(55). If such a situation occurs, the axis is first moved to the overrun position and then back to the required position. The overrun should not be programmed smaller than BLS. In case it is, the BLS is used as overrun.

See also chapter 1 about drive types.

Parameter 44 Overrun wait time

Range : 0 - 9999

Unit : msec

Default : 500

Function

Wait time at overrun position before the axis starts positioning in the opposite direction.

Parameter 45 Maximum operating speed

Range : 1 - 9999

Unit : mm/s

Default : 200

Remark

Only if 'Control type' (21) is set to 3.

Function

This is the maximum speed at which the axis will travel. Normally this value should be programmed to the maximum possible speed of the axis, when the control signal is at maximum. This value may also be programmed to a lower value, to limit the maximum speed the axis will travel.

Do not program this value higher than the axis can manage, this will have a bad effect on the control system.

Parameter 46
X-limit

Range : 0.0 - 9999.99
Unit : mm
Default : 9999.99

Remark

Only if 'Control type' (19) is set to 3.

Function

To define an area within which the X-axis can move at normal speed.
If the X-axis position is smaller than X-limit, the X-axis moves at normal speed. If the X-axis position is larger than X-limit, the X-axis moves at the speed, as programmed at 'Limit speed'(47).

Parameter 47
Limit speed

Range : 0.0 - 100.0
Unit : %
Default : 50.0

Remark

Only if 'Control type' (19) is set to 3.

Function

Speed value at which the axis will move when the X-axis is outside the area defined by 'X-Limit(46). The speed is programmed as a percentage of the maximum speed.
This speed setting is also used when the input LSX is active.

Parameter 48
Acceleration, 0 to max.


Range : 0 - 9999
Unit : msec
Default : 200

Remark

Only if 'Control type' (19) is set to 3.

Function

This is the nominal acceleration of the axis, used to control the axis from zero to maximum speed when the axis must move to a new position. This parameter must be programmed as the time in which the axis accelerates from zero to maximum speed.



Parameter 49 Deceleration, max. to 0

Range : 0 - 999
Unit : msec
Default : 200

Remark

Only if 'Control type' (19) is set to 3.

Function

This is the nominal deceleration of the axis, used to control the axis from maximum to zero speed when the axis comes into position. This parameter must be programmed as the time in which the axis decelerates from maximum to zero speed.

Parameter 50 Stop deceleration

Range : 1 - 9999
Unit : msec
Default : 200

Remark

Only if 'Control type' (19) is set to 3.

Function

Quick deceleration of the axis in case of a forced stop.

This rate of deceleration is used when normal operation is interrupted, for instance when the stop button is pressed on the control or a forced stop has been generated.

Parameter 51 P-gain

Range : 0.0 – 9999.9
Unit : -
Default : 2.5

Remark

Only if 'Control type' (19) is set to 3.

Function

Proportional gain factor for the axis.

This gain factor defines the response to changes in the control signal. A high gain gives a quick response, if the gain is too high it will cause oscillation.

Parameter 52 **I-gain**

Range : 0 - 9999
Unit : -
Default : 1

Remark

Only if 'Control type' (19) is set to 3.

Function

Integral gain factor for the axis.

The I-gain is used for accurate positioning of the axis.

Parameter 127 **Tracking error enable**

Range : 0 - 1
Unit : -
Default : 0

Remark

Only if 'Control type' (19) is set to 3.

Function

Tracking error limitation for the X-axis movement.

- 0 = off;

- 1 = on;

Parameter 128 **Tracking error margin**

Range : 0 - 9999.9
Unit : mm
Default : 0.00

Remark

Only if 'Control type' (19) is set to 3.

Function

This parameter defines the maximum allowed tracking error. When during operation this margin is exceeded, the controller will go to stop and the following message will appear on the screen:



Parameter 53
Positioning tolerance

Range : 0.01 - 9999.99
Unit : mm
Default : 0.01

Remark

Only if 'Control type' (19) is set to 1 or 2.

Function

To set a range in which no new positioning takes place.

The axis will position to the new programmed position if the difference between the actual position and the new position is greater than this tolerance. If the difference is smaller the axis will stay at its actual position.

Parameter 54
AC brake enable

Range : 0 - 1
Unit : -
Default : 0

Remark

Only if 'Control type' (19) is set to 1 or 2.

Function

Enable the brake output 'BRK'. This can be used to control an AC motor with brake.

0 = no brake signal

1 = enable brake signal

If this signal is used, make sure to map the brake signal to an available digital output. The brake signal is 'low-active': during positioning the signal is high, it will become low when the brake must be applied.

Parameter 55
Brake delay

Range : 0 - 9999
Unit : msec
Default : 0

Remark

Only if 'Control type' (19) is set to 1 or 2 and 'AC Brake enable' to 1.

Function

Delay time before AC brake is activated. The delay starts when the speed is set to 0.

Parameter 56
Brake point low speed <

Range : 0 - 9999
Unit : counts
Default : 10

Remark

Only if 'Control type' (19) is set to 1 or 2.

Function

Switch point from low speed to zero in the downcounting direction.

Parameter 57
Brake point low speed >

Range : 0 - 9999
Unit : counts
Default : 10

Remark

Only if 'Control type' (19) is set to 1 or 2.

Function

Switch point from low speed to zero in the upcounting direction.

Parameter 58
Brake point high speed <

Range : 0 - 9999
Unit : counts
Default : 100

Remark

Only if 'Control type' (19) is set to 2.

Function

Switch point from high speed to low speed in the downcounting direction.

Parameter 59
Brake point high speed >

Range : 0 - 9999
Unit : counts
Default : 100

Remark

Only if 'Control type' (19) is set to 2.

Function

Switch point from high speed to low speed in the upcounting direction.

Parameter 60
Stop time

Range : 0 - 9999
Unit : msec
Default : 0

Remark

Only if 'Control type' (19) is set to 1 or 2.

If 'AC brake enabled' (54) is set to 1, this parameter is not available.

Function

Delay time before switching off low speed after Brake point low speed (54/55) has been reached.

Parameter 61
DC low speed <

Range : 1 - 100
Unit : %
Default : 4

Remark

Only if 'Control type' (19) is set to 1 or 2.

Function

This is the output voltage for low speed movement in the negative direction. This parameter must be programmed if a DC motor drive is controlled with the analog output. It is programmed as a percentage of the maximum output voltage (10 V).

Parameter 62
DC low speed >

Range : 1 - 100
Unit : %
Default : 4

Remark

Only if 'Control type' (19) is set to 1 or 2.

Function

This is the output voltage for low speed movement in the positive direction. This parameter must be programmed if a DC motor drive is controlled with the analog output. It is programmed as a percentage of the maximum output voltage (10 V).

Parameter 63
DC high speed <

Range : 1 - 100
Unit : %
Default : 80

Remark

Only if 'Control type' (19) is set to 2.

Function

This is the output voltage for high speed movement in the negative direction. This parameter must be programmed if a 2-speed DC motor drive is controlled with the analog output. It is programmed as a percentage of the maximum output voltage (10 V).

Parameter 64
DC high speed >

Range : 1 - 100
Unit : %
Default : 80

Remark

Only if 'Control type' (19) is set to 2.

Function

This is the output voltage for high speed movement in the positive direction. This parameter must be programmed if a 2-speed DC motor drive is controlled with the analog output. It is programmed as a percentage of the maximum output voltage (10 V).

Parameter 65 Acceleration ramp

Range : 5 - 9999
Unit : msec
Default : 5

Remark

Only if 'Control type' (19) is set to 1 or 2.

Function

The nominal acceleration time, in which the axis accelerates from low speed to high speed. This parameter must be programmed if 2-speed DC motor drives are used.

Parameter 66 Braking ramp

Range : 5 - 9999
Unit : msec
Default : 5

Remark

Only if 'Control type' (19) is set to 1 or 2.

Function

The nominal deceleration time, in which the axis decelerates from high speed to low speed. This parameter must be programmed if 2-speed DC motor drives are used.

2.2.6. I/O

Parameter 67 Unipolar

Range : 0 - 1
Unit : -
Default : 0

Function

Function to switch unipolar control on/off. When set to 1, the analog speed output will only output a positive signal, regardless of the direction the axis is moving. This can be used to connect a frequency regulator. See also chapter 1 about unipolar control.<https://www.machinemfg.com/>

Parameter 68
In Position tolerance

Range : 0.01 - 9.99
Unit : mm
Default : 1.0

Function

The “in-position”(IP) output becomes active if the difference between the actual position and the programmed position is smaller than this tolerance. A cutting cycle will only advance if all axes are in position.

2.3. Angle control parameters

Parameter 69
Control enable

Range : 0 - 1
Unit : -
Default : 0

Function

Switch Angle control ON or OFF.

0 = No angle control

1 = Angle control

In case of angle control, the following I/O is used:

- digital outputs A+ and A-
- analog input AFB.

Parameter 70
Fixed angle

Range : 0.1 - 45.0
Unit : degrees
Default : 2.0

Remark

Only if the parameter ‘control enable’ (68) is set to 0.

Function

If there is no angle control, the (fixed) angle of the cutting blade can be programmed with this parameter. This value will be used for stroke and force computations.

Parameter 71 Angle tolerance

Range : 0.0 - 45.0
Unit : degrees
Default : 0.1

Function


Define the tolerance for the angle positioning. When the blade moves to a new angle position, positioning stops when the angle is within the tolerance and the output A_IP becomes high.

Parameter 72 Angle prestop positive

Range : 0 - 9999
Unit : AD value
Default : 0

Function

Due to the inertia of the Angle system there can be some overshoot after the control output has been switched off. To prevent such overshoot, the 'Angle prestop' can be programmed. This parameter can be regarded as a programmable offset. The control will take this offset into account when positioning the Angle. When the Angle system approaches the programmed position, the control output is switched off at a certain distance (Angle prestop) before the Angle has reached position. The 'Angle prestop positive' must be programmed for Angle movement in the positive direction.



The value is programmed in AD-points: a converted digital value of the position feedback voltage of the potentiometer.

Parameter 73 Angle prestop negative

Range : 0 - 9999
Unit : AD value
Default : 0

Function

This parameter has the same definition as parameter "Angle Prestop Positive" but only in the negative direction of the angle adjustment (smaller angle).

Parameter 120
In position tolerance

Range : 0.0 - 9.9
Unit : degrees
Default : 0.2

Function

Define the tolerance for activating the angle in-position output signal. This in-position signal is independent from the prestop settings.

Parameter 74
Angle reference table

Range : -
Unit : -
Default : -

Function

Press ENTER to open the screen with the angle reference table. In this table, the relation between the blade angle and the feedback voltage can be programmed.

	Angle	AD-Value
Minimum	0.0	100
	3.0	2000
	7.0	3000
Maximum	10.0	4095

Angle: program a known angle value for the blade.

AD-value: program the required feedback voltage for this angle. The feedback voltage must be programmed in the range 0-4095, which represents the input voltage in the range 0-10V. Use the diagnostic mode to find the correct AD-values. Move the blade to and angle, measure the angle position and notice the corresponding AD-value from the analog input.

Parameter 75 Angle material table

Range : -
Unit : -
Default : -

Function

Press ENTER to open the screen with the angle material table.

	M1	M2	M3	M4	M5	M6
0 %	1.0	0.0	0.0	0.0	0.0	0.0
25 %	2.5	0.0	0.0	0.0	0.0	0.0
50 %	5.0	0.0	0.0	0.0	0.0	0.0
75 %	7.0	0.0	0.0	0.0	0.0	0.0
100 %	10.0	0.0	0.0	0.0	0.0	0.0
Max =	5.0	10.0	8.0	6.0	3.0	7.0

In this table the cutting angle can be programmed as a function of sheet thickness and sheet material. If this table is programmed, the angle is precomputed for each cutting step in a program.

The plate thickness is indicated in the vertical column, as a percentage of the maximum thickness (parameter 13, 'Maximum thickness'). For various plate thickness values, the required angle value can be programmed.

These setpoints can be programmed for each material (column M1-M6).

2.4. Gap control parameters

2.4.1. GAP

Parameter 76 Control enable

Range : 0 - 1
Unit : -
Default : 0

Function

Program Gap control on or off.

0 = No gap control

1 = Gap control

In case of 1, the following I/O is used:


- digital outputs G1+ and G1-
- analog input GFB.

Parameter 77 Prestop positive

Range : 0 - 9999
Unit : AD value
Default : 0

Function

Due to the inertia of the Gap system there can be some overshoot after the control output has been switched off. To prevent such overshoot, the 'Gap prestop' can be programmed. This parameter can be regarded as a programmable offset. The control will take this offset into account when positioning the Gap. When the Gap system approaches the programmed position, the control output is switched off at a certain distance (Gap prestop) before the Gap has reached position. The 'Gap prestop positive' must be programmed for Gap movement in the positive direction.



The value is programmed in AD-points: a converted digital value of the position feedback voltage of the potentiometer.

Parameter 78 Prestop negative

Range : 0 - 9999
Unit : AD value
Default : 0

Function

This parameter has the same definition as parameter "Gap Prestop positive" but only in the negative direction of the gap adjustment (smaller gap).

Parameter 121 In position tolerance

Range : 0.01 - 9.99
Unit : mm
Default : 1.0

Function

Define the tolerance for activating the Gap in-position output signal. This in-position signal is independent from the prestop settings.

Parameter 79 Gap reference table

Range : -
Unit : -
Default : -

Function

Press ENTER to open a screen with the gap reference table. In this table, the relation between the gap and the feedback voltage can be programmed

	Gap	AD-Value
Minimum	0.08	400
	0.40	2000
	0.70	2900
Maximum	1.00	3800

Gap: program a known gap value for the blade.

AD-value: program the required feedback voltage for this gap. The voltage must be programmed in the range 0-4095, it will be converted to an input voltage in the range 0-10V. The adjustment procedure to find the correct AD-values is similar to the procedure for angle values as described in the previous section.

Parameter 80 Gap material table

Range : -
Unit : -
Default : -

Function

Press ENTER to open a screen with the gap material table.

	M1	M2	M3	M4	M5	M6
0 %	0.05	0.00	0.00	0.00	0.00	0.00
25 %	0.35	0.00	0.00	0.00	0.00	0.00
50 %	0.49	0.00	0.00	0.00	0.00	0.00
75 %	0.80	0.00	0.00	0.00	0.00	0.00
100 %	1.00	0.00	0.00	0.00	0.00	0.00
Max =	5.0	10.0	8.0	6.0	3.0	7.0

In this table the gap can be programmed as a function of sheet thickness and sheet material. If this table is programmed, the gap is precomputed for each cutting step in a program. The sheet thickness is indicated in the vertical column, as a percentage of the maximum thickness (parameter 13, 'Maximum thickness'). For various plate thickness values, the required gap value can be programmed. These setpoints can be programmed for each material (column M1-M6).

2.4.2. GAP 2

Parameter 81 Control enable

Range : 0 - 1
Unit : -
Default : 0

Function

Program control for a second gap unit (Gap2) on or off.

0 = No gap control

1 = Gap control

In case of 1, the following I/O is used:

- digital outputs G2+ and G2-
- analog input GFB.

Parameter 82 Prestop positive

Range : 0 - 9999
Unit : AD value
Default : 0

Function

The same as parameter 77, but now for Gap 2.

Parameter 83 Prestop negative

Range : 0 - 9999
Unit : AD value
Default : 0

Function

The same as parameter 78, but now for Gap 2.

Parameter 122 In position tolerance

Range : 0.01 - 9.99
Unit : mm
Default : 1.0

Function

Define the tolerance for activating the Gap in-position output signal. This in-position signal is independent from the prestop settings.

Parameter 84 Gap2 reference table

Range : -
Unit : -
Default : -

Function

Press ENTER to open a screen with the gap2 reference table. See parameter 'Gap reference table' (79) for more information.

2.5. Stroke control parameters

Parameter 85 Stroke mode

Range : 0 - 2
Unit : -
Default : 0

Function

0 = No stroke option ('Stroke length' not available in user interface)

1 = Stroke length using timer

2 = Stroke length using analog feedback (using input 'SFB')

In case of 1 and 2, the following I/O can be used:

- digital output EOS (End of Stroke)
- analog input SFB (only system 2)

When programmed to 2, the required stroke length in a cutting step is computed from angle setting, sheet position and cutting length. The user can change this as desired. The stroke position is measured through analog input 'SFB'.

When programmed to 1, the stroke length function is handled by a timer. At parameter 87 the maximum possible stroke length is programmed, at parameter 88 the necessary time is programmed to reach this maximum stroke. In a cutting step, the stroke length is computed as a percentage of the maximum stroke length (parameter 87). From this, the necessary time for a stroke is computed.

When the programmed stroke length is reached during a cutting step, the EOS output becomes high.

Parameter 86 **Sheet position mode**

Range : 0 - 2
Unit : -
Default : 0

Function

To enable or disable the parameter Sheet position in the user interface.

0 = Sheet position not programmable, not available in the user interface (default)

1 = Sheet position programmable for a program. The parameter will appear in the area where there is material, thickness etc.

2 = Sheet position programmable in each step.

Parameter 87 **Minimum stroke**

Range : -999 - 0
Unit : mm
Default : 0

Remark

This parameter must be programmed when 'stroke mode' is set to 1.

Function

This is the stroke distance when the blade is positioned on the upper dead point. Stroke position zero is defined as the upper side of the table, the minimum stroke is always negative

Parameter 88 **Maximum stroke**

Range : 0 - 999
Unit : mm
Default : 0

Remark

This parameter must be programmed when 'stroke mode' is set to 1.

Function

This is the actual stroke distance, starting at the edge of the table.

Parameter 89 T7: Stroke time

Range : 0 - 9999
Unit : msec
Default : 0

Remark

This parameter must be programmed when 'stroke mode' is set to 1.

Function


This is the time necessary to reach the maximum stroke length, as programmed at parameter 86. When that programmed time has elapsed, the output EOS will become active. The user can program the desired stroke length as a percentage (0-100%) of the maximum stroke length. This percentage value can be programmed in every step with the Stroke length parameter.

Parameter 90 Stroke reference table

Range : -
Unit : -
Default : -

Function

Press ENTER to open a screen with the Stroke reference table. In this table, the relation between stroke length and feedback voltage (input SFB) can be programmed.



	Stroke	AD-Value
Minimum	-50	100
	0	1000
	20	1500
Maximum	100	3500

Stroke: program a known stroke value for the blade.

AD-value: program the required feedback voltage for this stroke. The input voltage must be programmed in the range 0-4095, representing an input voltage in the range 0-10V.


The adjustment procedure to find the correct AD-values is similar to the procedure for angle values as described in section 2.5.

Parameter 91 Rotation offset

Range : -9999 - 9999
Unit : mm
Default : 0

Function

To program the offset of the rotation point of the blade with respect to the left side.



Parameter 92 Prestop

Range : 0 - 255
Unit : AD-points
Default : 0

Function

To stop the shear before the computed stroke length is reached. Due to the inertia of the system it is possible that the shear has a slight overshoot when it is stopped at the computed value. The programmed 'prestop'-value is subtracted from the computed value, creating an EOS (end of stroke) output signal at an earlier moment than the programmed moment.

Parameter 114 Opening enable

Range : 0 - 1
Unit : -
Default : 0

Function

- 0 = disabled
- 1 = enabled

When disabled the blade will open to the minimum stroke position. Also when a sheet offset is programmed the opening at the sheet position will be equal to the minimum stroke value, not taken the thickness into account.

When enabled the opening of the blade after a stroke can be programmed in the program constants page (110 Opening above sheet...= distance in millimeters).

2.6. Force control parameters

The DAC-360 can control one or more proportional pressure valves. If there is only one generic pressure valve on the machine refer to chapter 2.6.1. If there is a separate valve for the sheet clamping system (downholders) refer to chapter 2.6.2.

2.6.1. Main force

Parameter 93 Main force enable

Range : 0 - 1
Unit : -
Default : 0

Function

Enable or disable cutting force on the control.

0 = no control

1 = cutting force control enabled

Parameter 94 Cutting force factor

Range : 0.1 - 999.9
Unit : -
Default : 1.0

Function

The (initially) calculated cutting force is multiplied with this factor.

Parameter 95 Main force reference table

Range : -
Unit : -
Default : -

Function

Press ENTER to open a screen with the Cutting reference table. In this table, the relation between cutting force and control output voltage can be programmed.

Main force reference table		
	Cut	DA-Value
Minimum	10	500
	40	2048
Maximum	90	4095

Cut: program a known force value (in kiloNewtons) for a cut.

DA-value: program the required output voltage for this force. The output voltage must be programmed in the range 0-4095, it will be converted to an output voltage in the range 0-10V.

Parameter 97 **T1: Cutting force delay**

Range : 0 - 999
Unit : msec
Default : 0

Function

After the 'ST' input goes low, the control will start force control. This parameter can be used to program a delay before force control is started.

Parameter 129 **Cutting force ramp**

Range : 0 - 999
Unit : msec
Default : 200

Function

This parameter describes the ramp for the cutting force (increase/decrease). It is programmed as the time in which the force output increases from minimum to maximum voltage.

Parameter 99 P4: Opening force

Range : 0 - 100
Unit : %
Default : 50

Function

The force for steering the blade up. This value is programmed as a percentage of the maximum force (as programmed in the reference table).

Parameter 100 T3: Opening force delay

Range : 0 - 9999
Unit : msec
Default : 0

Function

When the 'end of stroke' is reached, the control will start opening control to move the blade up. This parameter can be used to program a delay before opening control is started. An opening delay is useful to overcome the response time of the clamping system and/or the pressure control system (in case of force control).

In the timing diagrams, this delay is called T3. When $\frac{1}{2}T3$ has elapsed, the signal B_UP is activated. When T3 has elapsed completely, the pressure output is activated (in case of force control).

Parameter 98 T4: Blade-up hold time

Range : 0 - 999
Unit : msec
Default : 0

Function

This is the time the output B_UP must remain active after UDP has been reached.

Parameter 130 Opening force ramp

Range : 0 - 999
Unit : msec
Default : 200

Function

This parameter describes the ramp for the opening force (increase/decrease). It is programmed as the time in which the force output increases from minimum to maximum voltage.

Parameter 131
Clamp force enable

Range : 0 - 1
Unit : -
Default : 0

Function

Enable or disable clamping force on the control using the main pressure output.

0 = no control

1 = clamping force control enabled

Parameter 102
P2: Clamping force

Range : 0 - 100
Unit : %
Default : 0

Function

Force value for the main force during clamping. It is programmed as a percentage of the maximum main force.

Parameter 103
T6: Clamping force delay

Range : 0 - 9999
Unit : msec
Default : 0

Function

Delay before the clamping pressure becomes active.

Parameter 104
T5: Clamping time

Range : 0 - 9999
Unit : msec
Default : 0

Function

The time the main force output stays active for clamping.

Parameter 132 Clamping force ramp

Range : 0 - 9999
Unit : msec
Default : 200

Function

This parameter describes the ramp for the clamping force (increase/decrease). It is programmed as the time in which the force output increases from minimum to maximum voltage.

Parameter 115 GAP force enable

Range : 0 - 1
Unit : -
Default : 0

Function

Enable or disable gap force on the control using the main pressure output.

0 = no control

1 = clamping force control enabled

Parameter 133 Angle force enable

Range : 0 - 1
Unit : -
Default : 0

Function

Enable or disable angle force on the control using the main pressure output.

0 = no control

1 = angle force control enabled

Parameter 116 P1g: GAP Force

Range : 0 - 100
Unit : %
Default : 0

Function

Force value for the main force during GAP adjust. It is programmed as a percentage of the maximum main force.

Parameter 134
T6: GAP force delay

Range : 0 - 9999
Unit : msec
Default : 0

Function

Delay before the GAP pressure becomes active.

Parameter 135
GAP force ramp

Range : 0 - 9999
Unit : msec
Default : 200

Function

This parameter describes the ramp for the GAP force (increase/decrease). It is programmed as the time in which the force output increases from minimum to maximum voltage.

Parameter 136
Position angle after GAP

Range : 0 - 1
Unit : -
Default : 0

Function

Determines wheater the Angle and Gap are positioned at the same time or sequentially after each other.

0 = Angle and Gap are positioned at the same time

1 = First the GAP is positioned and after the Angle

Parameter 137
T12: Angle after GAP delay

Range : 0 - 9999
Unit : msec
Default : 0

Function

Delay time between the end of GAP adjustment and start of angle adjustment.

Parameter 138 T11: Angle force delay

Range : 0 - 9999
Unit : msec
Default : 0

Function

Delay before the Angle pressure becomes active.

Parameter 139 Angle force ramp

Range : 0 - 9999
Unit : msec
Default : 200

Function

This parameter describes the ramp for the Angle force (increase/decrease). It is programmed as the time in which the force output increases from minimum to maximum voltage.

Parameter 101 P1a: Angle Force

Range : 0 - 100
Unit : %
Default : 0

Function

Force value for the main force during Angle adjust. It is programmed as a percentage of the maximum main force.

Parameter 140 P1: Angle/Gap force

Range : 0 - 9999
Unit : kN
Default : 0

Function

Force value in case of angle or gap control.

If the force is controlled and angle control or gap control is implemented, the main force is controlled at this value whenever angle or gap are positioned.

Parameter 141
T10: Angle/Gap force dly

Range : 0 - 9999
Unit : msec
Default : 0

Function

Delay before the angle/GAP pressure becomes active.

Parameter 142
Angle/Gap force ramp

Range : 0 - 9999
Unit : msec
Default : 200

Function

This parameter describes the ramp for the Angle/GAP force (increase/decrease). It is programmed as the time in which the force output increases from minimum to maximum voltage.

2.6.2. Clamping force

Below mentioned parameters only apply for system having a separate pressure valve to control the clamping force!!

Parameter 105
P2: Clamping force enable

Range : 0 - 1
Unit : -
Default : 0

Function

Enable or disable clamping force on the control using the separate pressure output.

0 = no control

1 = clamping force control enabled

Parameter 106
Clamping force ramp

Range : 0 - 9999
Unit : msec
Default : 200

Function

This parameter describes the ramp for the clamping force (increase/decrease). It is programmed as the time in which the force output increases from minimum to maximum voltage.<https://www.machinemfg.com/>

Parameter 107 T2: Clamping force delay

Range : 0 - 9999
Unit : msec
Default : 0

Function

Delay before the output is controlled for clamping.

Parameter 104 T5: Clamping time

Range : 0 - 9999
Unit : msec
Default : 0

Function


The time the clamping force output stays active for clamping. (This parameters is only available if mainforce is disabled).

Parameter 108 Clamping reference table

Range : -
Unit : -
Default : -

Function

Press ENTER to open a screen with the Clamping reference table. In this table, the relation between clamping force and control output voltage can be programmed.



	Clamp	DA-Value
Minimum	3	0
	6	2048
Maximum	9	4095

Cut: program a known force value (in kiloNewtons) for a cut.

DA-value: program the required output voltage for this force. The output voltage must be programmed in the range 0-4095, it will be converted to an output voltage in the range 0-10V.

Parameter 151
Idle force

Range : 0 - 4095
Unit : DA-points
Default : 0

Function

Force value (in DA-points) that is applied on the analog output when the controller is started.

2.7. Part support

The part support function is intended to support the cutted material during positioning against the backgauge in the machine (thin sheets). The DAC-360 provides 2 digital output pins and some parameters to control such a system. Since there are no inputs to connect an End of travel signal, it is advised to connect the (normally closed) EOT switch in series with the output of the DAC-360.

Parameter 143
Control enable

Range : 0 - 1
Unit : -
Default : 0

Function

Enable or disable the part support function.

0 = part support function disabled

1 = part support function enabled

Parameter 144
Default part support

Range : 0 - 1
Unit : -
Default : 0

Function

The default value of the part support parameter in a new program.

0 = part support function not active

1 = part support function active

Parameter 145
T13: PS_DN delay

Range : 0 - 9999
Unit : msec
Default : 0

Function

This parameter sets the delay between the activation of B_DN and PS_DN signal.

Parameter 146
T14: PS_DN pulse

Range : 0 - 9999
Unit : msec
Default : 0

Function

This parameter sets the duration of the PS_DN signal. Note that if the duration of the B_DN signal is shorter than the time programmed in this parameter, the PS_DN signal will be deactivated by the falling edge of B_DN.

Parameter 147
T15: PS_UP delay

Range : 0 - 9999
Unit : msec
Default : 0

Function

This parameter sets the delay between the activation of UDP and PS_UP signal.

Parameter 148
T16: PS_UP pulse

Range : 0 - 9999
Unit : msec
Default : 0

Function

This parameter sets the duration of the PS_UP signal.

Parameter 149
Park PS_DN

Range : 0 - 1
Unit : -
Default : 0

Function

This parameter sets the value of the PS_DN signal when the part support is disabled in the operator interface

Parameter 150
Park PS_UP

Range : 0 - 1
Unit : -
Default : 0

Function

This parameter sets the value of the PS_UP signal when the part support is disabled in the operator interface


3. I/O assignments

3.1. Introduction

The control has several programmable features. These features can be enabled or disabled in software. Depending on these features, a number of logical signals can be mapped to the I/O pins of the control.

This means the system programmer can enable the necessary signals and assign them to output pins. The I/O settings should be adjusted by authorized personnel only.

Example:




The example picture above shows an example of a possible mapping of output pins. In the picture, pins 5 - 8 are allocated for the movement of a 2-speed AC drive, fast and slow in both directions. If the system has a servo drive, those signals are not necessary. Then you could delete these connections (the intersections) and use output 5 - 8 for other purposes. See also the schematics in part I of this manual for connection examples.

The I/O mapping displayed in the machine parameter menu is read only.


To view and edit the I/O allocation mode:

- Select the program constants menu and place the cursor on parameter 124 "service menu";
- Enter the code 963 and press ENTER;

The following screen appears:



Each choice opens a sub-menu with an array of the logical signals and available connector pins. The screen for digital inputs looks as follows:



In the top row, the available connector pins are shown. In the left column, the logical signals are listed. The symbol \odot indicates that there is a connection between the pin and the logical signal. A signal is linked to an input pin as follows:

- move the cursor with the arrow keys and +/- keys to the necessary intersection;
- press ENTER.

To erase a connection, go to it with the cursor and press ENTER. The connection will disappear.

The numbers 5-8 and 13-16 refer to the digital inputs of the DAC. '0' is a logical FALSE. If a signal is linked to this, it is always regarded as low (not active). '1' is a logical TRUE. If a signal is linked to this, it is always regarded as high (active).

For digital outputs the method works similar. In the case of outputs, several logical signals can be mapped to the same output pin. They are processed as a logical OR: if one or more of these signals become high, the output pin becomes high.

3.2. List of I/O signals

Digital input signals

Code	Name	Description
UDPIN	UDP input	Input to indicate blade is in the (mechanical) Upper Dead Point.
MR	Machine Ready	Signal that indicates the machine is ready. When it is low, the control cannot be started and digital outputs and pressure outputs are disabled. When it is high, the control can be started and the Hours counter (parameter 91) keeps track of the time. When this signal is not mapped on an input pin the controller will display an error message at every start up of the system
ST	Step input	Input to change step
PEDAL	Start cut	Input for external signal to start cut
BR	Blade Return	Independent input to move the cutting blade up, typically used for pushbutton
R	Retract	Retract request signal. The Retract signal is only accepted during part of a cutting cycle. Please see the timing diagram to check the supported interval, as indicated by 'RetractEnable'.
EXS	External Start	Input to start the control
X_RES	Reset X	Reset X position to 0 (support decoiling)
LSX	Low Speed X-axis	Move X-axis with reduced speed (limit speed parameter)
RTSIN	Return to Sender	X-axis moves to the front side of the machine as long as this input is active. Applicable for systems with RTS function
KEY	Program enable	Signal to block or enable programming on the control.
RFC	Reference correction	Input signal for position correction. If high, the current position value is copied from the currently programmed position.
G2_ST	Start Second gap	Start input for second gap.
G1_ST	Start first gap	Start input for first gap.
A_ST	Start Angle	Start input for angle.
X_ST	Start backgauge	Start input for backgauge.
RSD	Reference Search Direction input	Input for reference switch for X-axis.

Digital output signals

Code	Name	Description
UDP	Upper Dead Point	Upper Dead point has been reached.
RDY	Ready	Ready signal, to indicate that the control has finished positioning. In case of a shear system, this signal becomes high when the axis is in position and the Gap and Angle are set correctly. The RDY signal will remain high during retract.
NCS	NC Start	Control is started.
EOS	End Of Stroke	Stroke is finished, either position is reached or stroke time has elapsed
EOC	End Of Cycle	Program step is finished. Becomes active after a step change and ST goes from high to low
F1	Function output 1	General purpose programmable output
F2	Function output 2	General purpose programmable output
F3	Function output 3	General purpose programmable output
F4	Function output 4	General purpose programmable output
SC0	Stock Counter 0	Stock counter has reached 0 after downcounting
B_UP	Blade up	Move blade up
B_DN	Blade down	Move blade down
CLAMP	Clamping force	Indicate clamping pressure is active
XSAFE	X at safe position	Indicate X-axis is outside safety zone
XFR	X-axis Front zone	Programmed X-Axis in Front Zone
XBACK	X-axis Back zone	Actual X-axis position in Back Zone
RTS	Return-to-Sender	Indication of a program step with RTS function active
RTSTH	RTS Thickness	Programmed Thickness above RTS Thickness
PS_UP	Part support UP	Send part support down output
PS_DN	Part support DN	Send part support up output
G2_OK	Gap 2 OK	Gap 2 control ready
G2_IP	Gap 2 IP	Gap 2 in position
G2+	Gap2 open	Increase gap2 opening
G2-	Gap2 close	Reduce gap2 opening
G1_OK	Gap 1 OK	Gap 1 control ready
G1_IP	Gap 1 in position	Gap 1 in position
G1+	Gap open	Increase gap opening
G1-	Gap close	Reduce gap opening
A_OK	Angle control ready	Angle control circuitry ready
A_IP	Angle in position	Blade has reached correct angle
A+	Angle increase	Increase angle between table and shear
A-	Angle decrease	Reduce angle between table and shear
X_OK	X-axis ready	X-axis control ready

X_IP	Backgauge in position	X-axis has reached position
X++	Fast opening	Fast opening command for AC motor X-axis
X+	Opening	Opening command for AC motor X-axis
X-	Closing	Closing command for AC motor X-axis
X--	Fast closing	Fast closing command for AC motor X-axis
BRK	Brake (AC)	Brake signal for AC motor, equipped with brake system. This signal is 'low-active': during positioning the signal is high, it will become low when the brake must be applied.

Analog input signals

Code	Name	Description
SFB	Stroke Feedback	Position feedback of the shear, in case Stroke feedback is enabled.
GFB2	Gap2 feedback	Position feedback of the Gap2 opening, in case Gap system with position feedback is enabled.
GFB1	Gap1 feedback	Position feedback of the Gap1 opening, in case Gap system with position feedback is enabled.
AFB	Angle feedback	Feedback of angle value, in case angle control is installed.

Analog output signals

Code	Name	Description
CF	Cutting force	Control signal for the main pressure valve, which is used for various pressure control functions
CLF	Clamping force	Control signal for clamping pressure valve

4. Software settings


4.1. Parameter back-up

The control has various data stored in its memory: program parameters, machine parameters and I/O settings.

This data can be stored on a PC or it can be restored from a PC. Examples:

- If the control settings have become erratic, a set of default settings can be restored from the PC. <https://www.machinemfg.com/>
- If you have a number of controls that need the same settings, you only need to program one control and save its settings. After that, all other controls can import these settings from the PC.
- If your control is to be upgraded with new software, you should save your settings. When the control is upgraded, all settings are set back to default values. After the upgrade, you can restore your settings from the PC.

The PC and the control are connected with each other through a serial link. To save or retrieve this data, the following set-up is used:




2.i

The following equipment is required:

- a Personal Computer, equipped with Windows 2000 or higher;
- serial cable, RS-232 (Delem DNC);
- Delem back-up software for transmission of machine settings.

The Delem back-up software must be installed on the PC. All actions, storage and restoration of settings, are done with this program. Just make sure the necessary cables are connected and the DAC control is switched on.

To start the back-up tool, simply double-click its icon. A window appears:



After start-up, the two large buttons for back-up and restore cannot be selected yet. First, click on the button 'Connect...' to establish a connection between the software and the DAC control. If not successful, select a different serial port (COM1, COM2, etc.) and try again. If this still gives no positive result, check your cabling.

When the connection is established, the two buttons will be coloured to indicate they are enabled.

To store the control settings on the PC:

- click the button 'Backup';
- in the dialogue, select a filename and a location for the file with control settings.

To load control settings into the control:

- click the button 'Restore';
- in the dialogue, select the file with control settings that must be loaded.


A back-up operation includes all data that is present on the control.

A restore operation offers the possibility to restore only specific data to the control. As shown above, several types of data can be selected for restoration.

- Program Parameters: all production parameters for the operator, step parameters, etc.
- Program Constants: some program settings for the operator.
- Machine Parameters: machine settings of the control, as described in chapter 1. This includes the IO Configuration as described in chapter 2.

4.2. Upgrade control

The control can be updated with new software. For this procedure, you need the same set-up as described in the previous section:




2.j

In order to perform a successful update you need a program that will load the new software into the control. This program can be requested from Delem.

Note: before starting an update, first perform a back-up of your control settings. When the control is updated, all data is erased and the control is reset to factory default settings. See the previous section for more information about back-up and restore.

Make sure the necessary cables are connected and the DAC control is switched on. To perform the update, double-click the program icon. The Update program will appear in a new window.



Check if you have made a back-up of your control settings. Then click on the 'Update' button to load the new software into your control.


The control is updated. A 'progress bar' inside the window will indicate the progress. When the update is completed, the message 'Update successfull' appears in a new window. Press 'Exit' to finish the program.

When the update is finished, the control is reset to default settings. If necessary, use the Backup Tool to restore the saved settings.

4.3. Special access codes

There are several access codes to enter special menus of the control. These access codes should only be known and used by authorised service personnel.

Each code is entered on the page of the program constants, when the cursor is on the parameter Language.



2.k

The following codes are available:

852

Use this code to enter the machine parameter menu. See also chapter 1.

963

Use this code to enter the I/O allocation mode. See also chapter 3.

741

Use this code to enter the diagnostic mode of the control. See part III of this manual.

123123

Use this code to reset the hours counter and stroke counter to zero, e.g. after the system has had a maintenance check.

684684

Use this code to reset all control data to default values. All previous settings are lost: machine parameters, I/O settings, programmed products and tools.

Warning: when this code is entered, all programmed products and tools in the control are lost! You should make a backup of all data before entering this reset code.

4.4. Display codes

In the upper right corner of the screen, a status code is shown that indicates the current status of the control. Such a code can either be a status code or an error code.

The following table shows the possible status codes:

S0	Stopped	Waiting for the operator to press start while pump start is high
S1	Positioning	Not all axes are in position yet
S2	Wait for ST low	Waiting for STEP input falling edge
S3	Wait for EOS	Wait for EOS, generated by potentiometer or BR
S4	Wait for UDP	Wait for UDP, generated by potentiometer or STEP input
S5	Wait for STEP high	Waiting for STEP input rising edge
S6	Wait for end of retract	Waiting for end of retract when STEP is already high.
S7	Wait for safe X	Waiting until X-axis is in safe area

The following table shows the possible error codes:

E1..	Internal error (1)
E21	Power supply failure
E23	Encoder 1 error
E24	Encoder 2 error
E53	Invalid parameters
E56	No movement on X-axis
E57	No movement on A-axis
E58	No movement on G1-axis
E59	No movement on G2-axis
E94	Internal error (1)

(1) If this error occurs, reboot the control. If the error persists, contact your machine supplier.

Part III - Diagnostic program

To be able to test a DAC-360 control, it has been equipped with a diagnostic program.

1. Introduction

1.1. Remarks

With the test functions of the diagnostic program a service engineer can test the control and the interfacing with the system.


Before starting the diagnostic program it is wise to check the machine for moving parts. This is because during the diagnostic operation of the control no regulation of the axis is performed. With the diagnostic program you have to be careful because all I/O is controlled. All digital and analog outputs can be activated for motor movement or relay switching.

1.2. Test-menu

To select the diagnostic program the following steps have to be performed:

- Move the cursor to the program constants,
- select the parameter '124 Service menu',
- Type access code 741 and press ENTER.

The diagnostic screen of the control looks as follows:



The screenshot shows a diagnostic screen with a top navigation bar containing icons for a right arrow, a hand, a hand with a plus sign, a document, and a printer. Below the navigation bar, there are two main sections: 'Digital' and 'Analog'. The 'Digital' section is further divided into 'Inputs' and 'Outputs'. The 'Analog' section shows 'Ad' and 'Offset' values for three channels (O1, O2, O3) and three inputs (I1, I2, I3). At the bottom right, there is an 'Encoder' section showing '488 Ref Off'.

Digital				Analog		
Inputs		Outputs			Ad	Offset
5	1	1	0	17	0	-5
6	1	2	0	18	0	0
7	1	3	0	19	0	0
8	1	4	0	20	0	0
13	0	9	0	21	0	0
14	1	10	0	22	0	0
15	1	11	1	23	0	0
16	1	12	0	24	0	0

	Ad	Offset
O1	0	-5
O2	0	0
O3	0	0
I1	781	
I2	1808	
I3	1808	

Encoder
488 Ref Off

3.a

To end the diagnostic program with the 'STOP'-key. The control application will restart.

1.3. Test functions

Digital Inputs 5 - 8, 13 -16

These digits refer to the digital inputs of the control. To test the digital inputs, apply 24V to the inputs and check if they change to '1'.

Digital Outputs 1-4, 9-12, 17-24

These digits refer to the digital outputs of the control. To change an output from 0 to 1 or 1 to 0, move the cursor to the required output number and press ENTER.

To toggle the value of an output for a short time, move the cursor to the required output number and press the +/- key. The value is inverted as long as the +/- key is pressed. When the +/- key is released the output returns to its initial value.

Analog

Column with several analog I/O signals, inputs and outputs.

The analog output voltages can be set between -10V and 10V with the left and right arrow keys or by typing a DA-value. These are 12-bit values between -4095 and 4095. The offset voltage can be programmed in the same manner.

The analog inputs accept voltages between -10V and 10V. The voltage is indicated with 12-bit values between -4095 and 4095.

Encoder

Test the encoder input and the encoder counting. Use the 'Ref' field to check the encoder reference signal. When switched on, the input will accept a reference pulse from the encoder. When switched off, the input will ignore any reference pulse.

1.4. Service screens

The control status and I/O behaviour can also be monitored in the operation modes. In these modes, several service screens can be activated. The service screens are available in Automatic mode and Manual mode.

There are three service screens:

- control status
- signal status
- I/O status

When the control is stopped, a service screen is opened by pressing the Stop key continuously. When the control is started, a service screen is opened by pressing the Start key continuously.

The service screen appears.

UDPIN	G2_ST	EOC	G2_OK	A+
MR	G1_ST	F1	G2_IP	A-
ST	A_ST	F2	G2+	X_OK
PEDAL	X_ST	F3	G2-	X_IP
BR	RSD	F4	G1_OK	X++
R		SC0	G1_IP	X+
EXS	UDP	B_UP	G1+	X-
X_RES	RDY	B_DN	G1-	X--
KEY	NCS	CLAMP	A_OK	BRK
RFC	EOS	XSAFE	A_IP	

In this screen, the status of all internal I/O signals is shown.

Machine state:		S1 Positioning		
	Prog.	Actual	State	
X =	199.75	200.10	1	
A =	10.0°	2.7°	1	
G1 =	0.25	0.36	1	
G2 =	0.25	0.35	1	
S =	100	42		
CF =	90	45		
CLF =	9	3		

In this screen, the programmed and actual values of parameters is shown.

Digital				Analog		
Inputs		Outputs			AD	Offset
5	0	1	0	17	0	0
6	0	2	0	18	0	0
7	1	3	1	19	0	0
8	1	4	1	20	2016	
13	0	9	0	21	2016	
14	0	10	0	22	1954	
15	0	11	0	23		
16	0	12	0	24		
				Encoder		
				499995 Ref Off		

In this screen, the status of all physical I/O is shown.

A program (step) can be started in order to view the I/O behaviour. In the service mode, it is not possible to program parameters or I/O.

Press the keys <arrow down> and <arrow up> to browse through the service screens.
